

# NUCANOE QUICKCONNECT Foot Steering Kit

Included Hardware: [1] Steering Cable [1] Foot Steering Pedal [2] 7055 1" Mighty Bolts [2] 7056 Mighty Knobs

## 1. Attach Steering Cable to Foot Steering Pedal

- Attach steering cable to steering connector terminal on the inner side of the Foot Steering Pedal
- Nest steering cable into clamp and secure with cotter pin.



## 2. Attach Steering Assembly to Tracks

Insert Mighty Bolts into track and place steering assembly over bolts. Slide the system into a place that is comfortable for you, then secure with Mighty Knobs.



## 3. Attach Steering Cable to Swing Arm

- Push sleeve back on ball joint connector, then insert steering cable and release the sleeve.

- Place steering cable in bracket clamp and secure with cotter pin.

