

Frontier Casting Bar

Installation Instructions

Installation video available at http://www.nucanoe.com/owners-area/

1. Install Casting Bar Base & Support Arm – Support arm to the stern. Base slot and ring on pin (red circles) towards the center of the Frontier.



2. Install Vertical Bars on Frontier Base Connectors – Position "fingers" as shown in picture. Insert detent pin, from the center to the outside.



3. Connect Vertical Bar– Install through slider on Support Tube. Put female Collet Lock through



4. Install Cross Bar – Insert Vertical Tube in Cross Bar in desired orientation. Push downwards until Cross Bar "bottoms out" on Vertical Tube. Screw Collet Locks to snug.



5. Lock Slider – Tighten Cam Lock lever to lock Casting Bar.



6. READY FOR THE WATER! - Unlock Cam Lock and laydown flat when not in use.



