



## Pursuit Casting Bar

1. Install Casting Bar Bases & Support Arms – Using Left & Right sections as picture, with short support arms on the deck floor track and cam locks to the outsides. Lightly tighten support arm “Bases” on the deck floor.



2. Install Upper Track Bases – Position “Bases” on bow upper track as shown in picture, about  $\frac{1}{2}$ ” from the edge of the track. Tighten knobs to secure bases.



3. Position Collet Lock– Unscrew Collet Lock from the Cross bar. Install as shown in picture.



4. Install Cross Bar – Slide cross bar down left and right side till it “bottoms out” with bend facing to the stern as shown in in Fig. 1. Then screw collet locks back together till snug shown in Fig. 2.



Fig.1.



Fig.2.

5. Fold Casting Bar Down – As shown in the photo. This will set up base feet positioning.



6. Slide the support arms back till the Slider contacts the base of the end connectors as shown in picture. This will ensure the Casting Bar bases are properly positioned. Snugly tighten bases on deck floor track. Pull back the casting bar to upright and use Cam Lock levers to lock Casting Bar in place and you are good to go!

