Rod Tip Holders

Installation Instructions

Rod Tip Cover Plate


- When installed, Gear Vault Cover should be able to open to a vertical position
- Install screws to snug, but do not overtighten

Frontier 10

- Install the screws on the closed end (A) 8" from the bow and .50" beneath the gunwale
- o Install the top screw on the open end (B) .75" beneath the gunwale
- Install bottom screw

Frontier 12

- Install the screws on the closed end (A) 9" from the bow and 1.25" beneath the gunwale
- o Install the top screw on the open end (B) .75" beneath the gunwale
- Install bottom screw





Rod Clip Recommended Locations

Frontier 10

o Install adjacent to stern end of recess and .75" beneath gunwale

• Frontier 12

Install in place of bow gunwale Deck Rings reusing hardware





Position with open end up clip upward